

***HF-2000 Step Start PCB Parts List
August 19, 2012***

C901	1000uf 63V	Digi-Key P5586-ND
D901	1N5408G	Newark 42K2941
R901	1K Ohm 10W	Newark 41K9215
R902	25 Ohm 10W	Mouser 28PR0009-25
R903	25 Ohm 10W	Mouser 28PR0009-25